



Part List for Model No. F18/32VM & F18/57VM

| Ref. No. | Part No. | Description |
|----------|----------|-----------------------------|
| 1 | 32VM01 | BOLT |
| 2 | 32VM02 | EXHAUST COVER |
| 3 | 32VM03 | BOLT |
| 4 | 32VM04 | CAP (F18/32VM) |
| 5 | 57VM04 | CAP (F18/57VM) |
| 6 | 32VM05 | SEAL |
| 7 | 32VM06 | SPRING |
| 8 | 32VM07 | O-RING |
| 9 | 32VM08 | HEAD VALVE |
| 10 | 32VM09 | O-RING |
| 11 | 32VM10 | COLLAR (F18/32VM) |
| 12 | 57VM10 | COLLAR (F18/57VM) |
| 13 | 32VM11 | WASHER |
| 14 | 32VM12 | CYLINDER (F18/32VM) |
| 15 | 57VM12 | CYLINDER (F18/57VM) |
| 16 | 32VM13 | O-RING |
| 14A | 32VM14A | 2-PC TYPE DRIVER (F18/32VM) |
| 14B | 57VM14A | 2-PC TYPE DRIVER (F18/57VM) |
| 15 | 32VM14B | 1-PC TYPE DRIVER (F18/32VM) |
| 16 | 57VM14B | 1-PC TYPE DRIVER (F18/57VM) |
| 17 | 32VM15 | BUMPER |
| 18 | 32VM16 | CAP SEAL |
| 19 | 32VM17 | STEPPED PIN |
| 20 | 32VM18 | BODY |
| 21 | 32VM19 | NOZZLE |
| 22 | 32VM20 | SPRING |
| 23 | 32VM21 | TRIGGER VALVE STEM |
| 24 | 32VM22 | O-RING |
| 25 | 32VM23 | O-RING |
| 26 | 32VM24 | TRIGGER VALVE GUIDE |
| 27 | 32VM25 | TRIGGER ASSEMBLY |
| 28 | 32VM26 | SAFETY GUIDE |
| 29 | 32VM27 | SPRING |
| 30 | 32VM28 | BUTTON |
| 31 | 32VM29 | SPRING |
| 32 | 32VM30 | SAFETY LEVER |

| Ref. No. | Part No. | Description |
|----------|----------|---------------------------|
| 33 | 32VM31 | ROLLED PIN |
| 34 | 32VM32 | SHAFT |
| 35 | 32VM33 | END CAP SEAL |
| 36 | 32VM34 | END CAP |
| 37 | 32VM35 | AIR PLUG |
| 38 | 32VM36 | ROLLED PIN |
| 39 | 32VM37 | ROLLED PIN |
| 40 | 32VM38 | BOLT |
| 41 | 32VM39 | COVER (F18/32VM) |
| 42 | 57VM39 | COVER (F18/57VM) |
| 43 | 32VM40 | SPACER |
| 44 | 32VM41 | SPACER |
| 45 | 32VM42 | SAFETY COVER |
| 46 | 32VM43 | CONTACT TIP |
| 47 | 32VM44 | SAFETY (F18/32VM) |
| 48 | 57VM44 | SAFETY (F18/57VM) |
| 49 | 32VM45 | FRONT PLATE (F18/32VM) |
| 50 | 57VM45 | FRONT PLATE (F18/57VM) |
| 51 | 32VM46 | BOLT |
| 52 | 32VM47 | GUIDING PLATE (F18/32VM) |
| 53 | 57VM47 | GUIDING PLATE (F18/57VM) |
| 54 | 32VM48 | SPACER |
| 55 | 32VM49 | ROLLED PIN |
| 56 | 32VM50 | NAIL GUIDE LINER |
| 57 | 32VM51 | MAGAZINE SEAT (F18/32VM) |
| 58 | 57VM51 | MAGAZINE SEAT (F18/57VM) |
| 59 | 32VM52 | PUSHER |
| 60 | 32VM53 | PUSHER GUIDE |
| 61 | 32VM54 | SPRING COVER |
| 62 | 32VM55 | SPRING |
| 63 | 32VM56 | ROLLED PIN (F18/32VM) |
| 64 | 57VM56 | ROLLED PIN (F18/57VM) |
| 65 | 32VM57 | MAGAZINE COVER (F18/32VM) |
| 66 | 57VM57 | MAGAZINE COVER (F18/57VM) |
| 67 | 32VM58 | SPRING |
| 68 | 32VM59 | MAGAZINE LATCH |