



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	MS9201	Bolt	40	WS1640	Support
3	30AB59	Washer	41	WS1641	Nut Plate
4	80A010	Bolt	42	MB041	Spring Washer
5	MS9204	Cylinder Cap	43	SR0061	Bolt
6	MS9205	Cap Seal	44	WS1644	Guide
7	MS9206	Piston Stop	45	WS1645	Rail
8	MS9207	Head Valve Cap	46	MC0051	Roller
9	MS9208	O-Ring	47	WS1647	Magazine Cover
10	MS9209	Compression Spring	48	WS1648	Nozzle
11	SR0046	O-Ring	49	WS1649	Plate
12	MS9211	O-Ring	50	MC0052	Compression Spring
13	MS9212	Head Valve Seat	51	WS1651	Bolt
14	MS9213	Gasket	52	WS1652	Safety B
15	MS9214	O-Ring	53	WS1653	Safety A
16	WS1616	Main Piston	54	WS1654	Latch
17	MS9216N	O-Ring	55	WS1655	Nose Plate
18	MS9217	Collar	56	WS1656	Bolt
19	WS1619	Driver Blade	57	WS1657	Upper Nose Plate
20	MS9219	O-Ring	58	WS1658	Spring Pin
21	MS9220	Cylinder	59	WS1659	Pin
22	WS1622	Bumper	60	WS1660	Guide Plate
24	04J223	End Cap	61	WS1661	Thread Pin
25	04J209	O-Ring	62	WS1662	Thread Pin
26	WS1626	Body	63	WS1663	Bolt
27	MS9235	Contact Lever	64	WS1664	Pusher Spring
28	SR0038	Spring Pin	65	WS1665	Roller
29	MS9238	Bolt	66	80A135	E-Ring
30	MS9237	Trigger	67	WS1667	Stop Pin
31	MS9239	Spring Pin	68	WS1668	Compression Spring
32	04J201	Lock Nut	69	WS1669	Pusher
33	MS9224	Trigger Valve Cap	70	WS1670	Pin
34	MS9226	Compression Spring	71	WS1671	E-Ring
35	MS9227	O-Ring	72	WS1672	Magazine
36	MS9228	Trigger Valve Stem	73	WS1673	O-Ring
37	MS9229	Trigger Valve Seat	74	MC0031	Exhaust Cap Ring
38	MS9230	O-Ring	75	MS9202A	Exhaust Cap
39	MS9249	Bolt			